



1

Combobulator Setup Screen <1481>

- Printer
- TRACE Station
- Service Code
- Max # Releasable
- Frame Label
- Additional Features
 - WIP Test Queues
 - Job Filter Logic

Printer (optional)
Canon TS3300 series (redirected 2)

Sort: [] [] []

Fill Condition (optional)
Queue is full when []
reaches 0 jobs/minutes.
 Auto-release queue

Trace Station
111 CBOB-SUB RCVD

Service Code WWS22 Stay in Combobulator

Max #Orders Releasable 10
modified 12/14/20 by CL

Frame Label
FTCLBL
 Assign FTC Bin
Bin Range: FTC

Stock Order Queue
 Hold Queue
 Subcontract Queue
 Auto FTC Queue
 Pinnable


OK

2

Assign Printer to Queue

- Used to set destination printer for this queue


- Blank will use the default printer
- Tray up
- Stock Orders



3

Add TRACE Station to Queue

- Allows for logging of jobs in this queue to a specified TRACE station
 - TRACE station is assigned when the job first enters the queue
 - Tray history details
 - TRACE Late Jobs Reporting
 - Archive Reporting



4

Add Service Code to Queue

- Ability to add a service code to jobs in this queue
 - Service code is applied when the job exits the queue
 - Customer Service Rep
 - Special Handling
 - Service to print on work ticket

Service Code

5

Max # Orders Releasable

- Sets the maximum number of orders to print / release from this queue when "Process All" is selected
 - Blank will release all orders in queue
 - Eliminates need to "Process Some"
 - Prevents unintentionally releasing entire queue

Max #Orders Releasable

6

Frame Label

- Select label to print for this queue
 - Frame pull – FTC
 - Assign FTC bin
 - Print any label from Form Editor
 - Print labels by right-clicking and selecting “print frame labels”
 - Key off label for job status

Frame Label

FTCLBL

Assign FTC Bin



7

WIP Test

- Ability to test a job in process to determine which queue will capture the job
 - Include details to view all queues job passed through
 - Test a specific tray or set number of trays

Job Combulator

Save MoveDown MoveUp Insert Delete Update Setup WIP Test

Name	Count	Age	Status
Unreviewed	9	83:17:08	
FTC - AUTO	3	134:22:05	100%
MFR Backorder	0		
Lab Redo	19	110:18:15	
Customer Service	10	127:18:56	

WIP Test

Include Detail in report

Test Specified Tray: 2001

Limit test to specified number of trays:

Cancel OK


Tray	Inv#	Patient	Routed to...
2001	723849	Tptw, Xssnk	88-Job on Hold
		[CAT: 4 Unreviewed]	
		54 Reviewed: [(1)]	
		[CAT: 85 FTC - AUTO]	
		8 Job Type: [L]	
		[CAT: 32 MFR Backorder]	
		12 Lens Style: [ACCOLADE FBS]	
		10 Lens Material: [TPY]	
		14 Service: []	
		8 Job Type: [L]	
		[CAT: 89 Lab Redo]	
		14 Service: []	
		[CAT: 21 Customer Service]	
		14 Service: []	
		[CAT: 87 Will Call Back]	
		14 Service: []	
		[CAT: 88 Job on Hold]	
		115 Job on Hold: []	



8

Job Filter Logic

- Routing Filter Logic – Wizard List <2252>
 - Detailed list of routing logic filters by queue



```
J:\vision\jrle\apfo.dat
4: Unreviewed
  1. Reviewed(54) == FALSE
  2. Service Description(73) == *
-----
85: FTC - AUTO Temp
  1. Job Type(8) == D
  2. Frame Lab Traced(105) == TRUE
  3. Reprocessed w/Tracing(106) == FALSE
  4. Lens Short Ordered(103) == TRUE
  5. Account(18) == 6
-----
32: MFR Backorder
  1. Lens Style(12) == RD*.ST28,ST35,STT*.DOUBLE*
  2. Lens Material(10) == H53
  3. Service(14) != OKCL
  4. Job Type(8) != M
  [1 and 2 and 3 and 4]
```



9

New Filter Options

- Circ or DBL Specified
 - Captures orders where the ECP has specified the Circ or the DBL
 - Allows the lab to review certain accounts and potential problematic frame information before starting a job

Queue Name	Description
Dr. Johnson	Jobs where Dr. Johnson has specified frame info

Job Inclusion Criteria			
	Data Type	Operator	Value(s)
1	Account	*	12345
2	DBL Specified	*	TRUE
3	Circumference Specifie	*	TRUE
4			
5			
6			
7			
8			
9			
10			
11			
12			

Optional Formula (e.g. *(1 or 2) and 3*)
 [1 and (2 or 3)]



10

New Sort Options

- Days Since Frame Received
 - Overrides default of “aging” for initial job selection
 - Ensures that the jobs printed are the ones that the lab has had the frame for the longest
 - Also available as a field in the Form Editor

Sort: Days Since Frame Rec

Fill Condition (optional): Queue is full when reaches 0

Auto-release queue

Sort options list: Days Since Frame Rec, DBL Specified, Delivery Method, Department, Digital MFR, Digitally Filled, REMOTE...

11

New Sort Options

- Ship Date
 - Overrides default of “aging” for initial job selection
 - Allows the lab to prioritize promise jobs

Sort: Ship Date

Fill Condition (optional): Queue is full when reaches 0

Auto-release queue

Sort options list: Ship Date, Slow Macro, Smallest Blank Diam, Stock Order Type, Stock Redirect, Stock Redirect Error

12

Calculate Digital Jobs in Combob

- Option to hold jobs in a queue until digital results are received
- Capture any digital failures in a specific queue for review
- Merge LDS values into job for print on work ticket



13

Receive Remote Pattern Before Job

- Patterns can be received before job is in-house
- Once job arrives, pattern is merged to job
- Allows customer to send pattern according to their workflow



14


Job Data Export

- Option to export job data upon entry into XML files and revisions to JSON files.
- The data created using this process is suitable for import into a database for reporting purposes on current work-in-process.
- This feature is licensed and activated as part of the Enterprise License Module.

15


Reprocess Rx's

- Ability to reprocess all jobs in any queue to apply new rules
 - Worktickets are not printed
 - Job stays in the Combobulator
 - Can be used on ANY queue
 - Including EDITS
 - Does not relog to any assigned TRACE station
 - Digital jobs not recalced



16

Queue release rate



- Allows defining by queue the amount of jobs to release per hour
 - Requires queues to be set to Auto Release
- Assists in consistent workflow or load balancing
- Set by day of week and hour
 - Release counts reset at the start of each selected hour

17

Queue release rate



- If less than defined are available to print, all jobs are printed and new jobs that fall into queue are printed as received until requested amount is fulfilled

Queue Release Rate		06:00 AM -	07:00 AM -	08:00 AM -	09:00 AM -	10:00 AM -	11:00 AM -	12:00 PM -	01:00 PM -
Day	Queue								
Workday	AR - Fin					20	20	20	20
Any Day	Edged - Surf		20	20	20	20	20	20	
Workday	AR - Surf	20	20	20	20				
Non-Workday									
Sunday									
Monday									
Tuesday									
Wednesday									

18

Pinnable Queues [wsr]

- Queues that hold jobs until “pin” is removed
 - Useful for directing jobs to specific staff or departments
- Can be set from Rx entry
 - In process job
 - New trayless entry job (REQ)
- To remove from queue, Unpin option must be selected



19

Error types in EDITS

- Error type
 - More general representation of job issues

Review by Error Type	>	Miscellaneous Edits	100
Review by Warning	>	Duplicate	23
Review by Origin	>	Cut out	11
Receive from Subcontractor, assign Cost and Tray#		Lens pick	32
Order Frames		Frame	14
Order Lenses		Pricing	22
Processor Rule			

20

Warning in EDITS

- Warnings
 - Specific breakdown by Rx Warning
 - Useful for assigning correct staff

Process to Specified Trays	EDGE TYPE OK?	1
Process All	NO PICK/SPECIFY	7
Process Some	OC OUTSIDE SHAPE	2
Manual Review	EYE SIZES AVAILABLE	2
Review by Error Type	BRIDGE SIZES AVAILABLE	3
Review by Warning	PRISM SAME DIRECTION!	1
Review by Origin	RX NOT PRICEABLE!	20
Receive from Subcontractor, assign Cost and Tray#	EYESZ NOT = TRACE...SPEC CSIZE?	2
Order Frames	3D FIT! CK BASE?	1
Order Lenses	EXTREME DECENTRATION	4
Reprocess Rx's	AR/SCR MISMATCH	19
	Coat Unavailable in Lens	1
	CONVEX ADD CURVE	1
	FRAME MARKED FOR NO-'G'	5
	Pick Lens Add not found	4
	Lens Not Found	17
	Miscellaneous Edits	27



21



22